



### Wiring the Painted Lady

Here's a basic wiring pattern. Modify the exact positioning of the ceiling runs of tapewire based on your interior plan. The vertical drop will go up all the stair-holes and still miss the door in the first-floor divider if it is close to the edges. The drop can go up to the roof and across the peak in one run. It is just-possible to fit tapewire on the Kneewall, but plan ahead for the juxtaposition of outlets and baseboard.

It may be easiest to wire the Tower Ceiling with it un-glued so you can put it on and take it off several times while you mark where the tapewire goes when it is folded.