

### The Main Loop:

The Housebody is assembled including the Attic Ceiling and Front Roof, but wiring is easiest if it is started before the Rear Roof, Foundation, or Dividers are attached.

The Main Loop goes up one Sidewall, across the Attic Ceiling, and down the other Sidewall with a 2" flap under the Base Floor on both ends. Feed the tapewire with the back on all in one piece, no folds, no connections. Don't cut off the roll until after all the tapewire is installed.

Pull some extra below the Base Floor and begin pulling of the backing. Tear off some backing and put it back on the flap, but leave some without backing to pull thru to the first floor area. One floor at-a-time, pull some extra, remove enough backing so the end will pull thru the e-slot and be in the next space, then pull the tapewire snug and rub it down. Repeat until all the tapewire is stuck down except the flaps below the Base Floor. Now you can cut off the roll.

