

Copper-to-copper and blue-to-blue

Run the Ceiling Loops from one side of the Main Loop to the other. Pay careful attention to the direction you are installing the tapewire to ensure the blue will overlap the blue lead of the Main Loop, and the copper will overlap the copper lead. Leave at least $1^{1/2}$ " overlap.

Secondary Ceiling Loops thru the Insets and over the Porch Ceilings are optional, but if you do these loops, bring the ends to less than 3/4" from the floor

