

## Connect the Main Loop to the Jack

In this application, the jack is connected to the main loop by running the Jack's Connection Wires through the floor in 1.5mm holes drilled with the EL66 tool (lots of spin, lots of clearing, very little push). Strip the wires before they go thru the floor, and eyelet them to the tapewire.