



Run the Main Loop in one piece with no breaks or connections from the cellar (if wiring during construction) or from the connection wire (after construction). Run thru the E-Slot cut in the Top Floor, then glue the Plug back in.