



Side Tap (-)

Center Tap (+)

The circles on the Attic Scence Run  show where a pocket will be necessary to keep the tapewire level with the marks.